

## Instruction to use Audio Device in the Class Room

	<p><b>STEP-1</b></p> <p><b>PLEASE TURN ON THE POWER SWITCH OF THE RACK</b></p>
	<p><b>STEP-2</b></p> <p><b>TURN ON THE MIKE (MIKE SWITCH IS ON THE BOTTOM)</b></p>
	<p><b>STEP-3</b></p> <p><b>TURN ON THE MIKE (MIKE SWITCH IS ON THE TOP)</b></p>

**FOR FURTHER ASSISTANCE, CALL Mr. PARMOD SINGHLA (9041744839) OR  
Mr. VIKAS CHOUDHARY (9882813769)**